

Bond Home - Fan

Compatible Control4 Systems:

Designed to work with OS 3.x+

Driver Download, Change Log & Documentation:

<https://drivercentral.io/platforms/control4-drivers/utility/bond-home>

Content

- [Dealer Notes](#)
 - [Driver Setup](#)
 - [Driver Properties](#)
 - [Fan Settings](#)
 - [Button Settings](#)
 - [Support](#)
 - [License Purchase & Assignment](#)
 - [Showroom and Free Trial](#)
 - [Warranty & Disclaimer](#)
 - [Developer Information](#)
-

Dealer Notes

- Bond Fans can have up to 8 speeds.
- Driver automatically builds the amount of speeds based on the connected device.
- All speeds do not need to be utilized. Adjust the *Speeds Used* property to set which speeds should be used.
- In addition to the main toggle button there are two other buttons provided by the driver: Increase Speed and Decrease Speed

- These buttons work only with fans that have support for increasing/decreasing speeds (not fireplace fans)
 - Fans may contain lights. Up to three lights may be available for control: Light, Up Light and Down Light.
 - Lights will have control output connections that can be linked to the Bond Light driver.
 - Bond Fan can be controlled using a Relay connection (ex. can be used with Control4's fan timer)
 - By default the Bond Fan will be shown under Comfort in the installed room
-

Driver Setup

1. Connect driver with a Bond Bridge fan or a Bond Fireplace fan
 2. If connected to Bond Bridge set *Speeds Used*, Bond Fireplaces always use Low(1), Medium(4), and High(8) speeds
 3. If fan contains lights visit the Connections tab and bind the Bond Light driver to the light you wish to control
-

Driver Properties

- *Driver Status*: Displays driver related information
 - *Driver Version*: Displays driver version
 - *Driver Actions*:
 - *Reset Speeds Used*: Reset Speeds Used for toggling the fan
 - *Show Icon In All Rooms*: Show icon under the Comfort section
 - *Hide Icon In All Rooms*: Hide icon in rooms
 - *Automatic Updates*: Allows the *Cloud Driver* to automatically update the driver when a new version is available
 - *Debug Mode*: Displays additional information on the lua tab for debugging purposes
-

Fan Settings

- *Device*: Device connected with the driver
 - *Speeds*: Speeds available in the driver
 - *Speeds Used*: Speeds utilized by the driver
 - *Light*: Status of connections with Bond Fan's light features
-

Button Settings

- *Speeds Toggle*: Toggle through speeds used
 - *Off*: Turn off fan
 - *Nothing*: Does nothing
-

Support

If you require additional driver assistance or are having some issues please visit our help desk: <https://help.drivercentral.io>

Showroom and Free Trial

All Cindev drivers for Control4 come with a 7-day trial. Simply add the DriverCentral licensing driver, *Cloud Driver*, along with this driver and you can fully test the driver before purchasing. Including Cindev drivers in your drivercentral showroom project will give you unlimited use without purchase.

Warranty & Disclaimer

www.cindev.com/terms-and-conditions

Developer Information

brought to you by:
Cinegration Development, LLC



www.cindev.com
www.drivercentral.io/cindev/

We are always looking to improve our drivers.
Please send your suggestions to: info@cinddev.com