


Grants/denies access to device connected to 'Access' connection output for a specified amount of time.

## TYPE FEATURES


Control: Relay Input	Access: Relay Output	Message Time	Verify Time	Verification	Show Length	Lockout
Required	Required	Required	Required	Required	Required	Optional

## EXPERIENCE

### Normal



### Verified



### Notes

- Make sure to allow for enough time to close the application and find the accompanying button that is unlocked by the Code Agent
- We suggest favoriting the Code Agent and the accompanying button in the same room right next to each other as shown in the example above
- If both **Access** and **Control** relay connections are not made when using the code type, the driver will enter an **OFFLINE** state
- Though the driver can be bound to any relay binding there may be limitations
  - Ex.: The lock proxy does not pass proxy commands correctly through the relay connection. There are workarounds but they are not recommended as they do not survive a reboot.