


Toggles between 'Verified' and 'Normal' states each time the correct code is entered.

TYPE FEATURES

Control: Relay Input	Access: Relay Output	Message Time	Verify Time	Verification	Show Length	Lockout
N/A	N/A	Required	N/A	Required	Required	Optional

EXPERIENCE



Notes

- Agent remains in the same state until the correct code is entered
- The dealer should either utilize the **Code Verified** and **Code No Longer Verified** events or should program based off the **Code Verified** conditional