

SÉURA®

Driver: Seura TV RS232/IR driver

Compatible Control4 Systems: 2.9.1

Compatible Hardware: Seura TV (Mirror Series)

Control Platform: RS232 (115200 Baud) or IR

Developed by: Cinegration LLC. <https://www.drivercentral.io/cinegration>

Initial Setup/Installation of Driver

TV Installation

Setup TV according to TV documentation.

Using RS232:

Create RJ-45 -> RS232 Cable (like below):

(TIA-568-B) ->

- W/OR -> Pin 3 (Controller)
- W/GR -> Pin 2 (Controller)
- W/BL -> Pin 5 (Controller)

Using IR:

(TIA-568-B) ->

- W/BL -> Ground
- BL -> IR In

Setup in Driver

- Add driver to project
- Set Connections
- Refresh Navigators

Developed by Cinegration LLC for Seura TV 2017.