

White Paper: Tekmar

8.29.2022

482 + 486 Wiring

Currently the 482 is the only approved method for controlling tekmar tN4 systems. Dealers can use the 486 cloud based control AND the 482 rs232 at the same time.

Changes made on any device (Control4, tekmar App, Thermostat) are updated on all systems.

Note: The Control4 driver POLLS thermostat information once a minute. Changes made on the app may take up to one minute to be reflected in the Control4 navigator.

To connect:

- Wire the Port connections together (c to c, tN4 to tN4)



<https://www.cindev.com>

<https://www.drivercentral.io/cindev/>

We are always looking to improve our drivers. Please send your suggestions to:

info@cindev.com