

LightSpeed MV-4k-4X1 Layouts



Compatible Control4 Systems:

Designed to work with OS 3.3.0+

Compatible Hardware

This driver supports the Lightspeed MV-4k-4X1 HDMI Multi Viewer

Driver Download, Change Log & Documentation:

<https://drivercentral.io/platforms/control4-drivers/audio-video/lightspeed-mv-4k-4x1>

Content

- [Overview/Features](#)
- [Dealer Notes](#)
- [Driver Setup](#)
- [Driver Properties](#)
- [Layout Button Settings](#)
- [Support](#)

- [License Purchase & Assignment](#)
 - [Showroom and Free Trial](#)
 - [Warranty & Disclaimer](#)
 - [Developer Information](#)
-

Overview/Features

Transform your viewing experience with the MV-4K-4X1, the ultimate 4K multi-view video processor. Effortlessly display up to four 4K/UHD video signals on a single screen with stunning 60Hz clarity. Choose from different layouts, and select what input displays on each display tile!

The accompanying Layout driver for the LightSpeed MV-4K-4X1 will allow you to add UI buttons to navigators for swapping to layout presets configured in Composer.

- 6 layouts to choose from including Original, PIP, Dual-View, H, Quad, Master
 - Automatically binds itself to the main LightSpeed MV-4K-4X1 driver for communication to the device
-

Dealer Notes

- For automatic binding of the buttons to work correctly, the main LightSpeed MV-4K-4X1 should be installed and configured before adding this driver to the project
 - PIP Position Property will only display if PIP is selected
-

Driver Setup

1. Make sure the main LightSpeed MV-4K-4X1 is already in the project and configured properly before adding the layout driver
 2. Add layout driver to project
 3. Configure the buttons preset as desired
 4. Refresh Navigators
-


Driver Properties

- *Driver Status*: Displays driver related information

- *Driver Version*: Displays driver version
- *Debug Mode*: Displays additional information on the Lua tab for debugging purposes

Layout Button Settings

Supported Layouts



- *Icon Style*: Set which layout you want to be selected on button press
- *PIP Position*: If the Icon Style is set to PIP, here you can set the position of the PIP for the layout
- *Select Input 1-4*: Set which input displays in each tile for the selected Layout/Icon Style

Support

If you require additional driver assistance or are having some issues please visit our help desk: <https://help.drivercentral.io>

Showroom and Free Trial

All Cindev drivers for Control4 come with a 7-day trial. Simply add the DriverCentral licensing driver, *Cloud Driver*, along with this driver and you can fully test the driver before purchasing. Including Cindev drivers in your drivercentral showroom project will give you unlimited use without purchase.

Warranty & Disclaimer

www.cindev.com/terms-and-conditions

Developer Information

brought to you by:
Cinegration Development, LLC



www.cindev.com

www.drivercentral.io/cindev/

We are always looking to improve our drivers.
Please send your suggestions to: info@cindev.com