

Receiver Modes

Installation

Install one instance of the driver for each room in which you want to utilize it.

Configuration

1. In the properties, select the receiver modes you want to have shown on the experience button
2. For each mode you have selected, attach programming in the programming tab for what should occur when that button is pressed.
Generally speaking, you want to have it change the mode on your receiver to the selected output type.

Change Log

20230718

- Fix icon(s) not properly rendering on navigators

20230627

- Initial Release