



Axion Touchpanel ELAN Driver

Overview

This driver integrates an Axion Touchpanel into the ELAN project. It is recommended to set the touchpanel to a static ip or assign a DHCP reservation.

Features

- System Reboot
- LED Control (only certain models)
- Screen Brightness Control
- System Volume/Mute Control
- System Mute Control

Quick Start Guide

- Add the touchpanel driver to project.
 - Enter the IP address of the touchpanel.
 - Enter the API port of the touchpanel. Default is 8080 unless otherwise configured.

Control

- Using the event mapper or any other aspect of ELAN that allows the use of registered commands, select the command/action for a given condition. When that condition is met, the command will execute on the driver and perform the appropriate actions on the device.

Change Log

Version 1

- Initial Release