


# Driver for integration: TV TCL [IR]

Mini Drivers for some streams available via IR Support: contato@4drivers.com.br



Choose a standard input on the driver if you want the TV to enter open channels (TV ANT) or Smart TV Google TV (or the mini app you want):

#### Default Input:

| {None} ~               |
|------------------------|
| {None}                 |
| MiniApp 10             |
| MiniApp 9              |
| MiniApp 8              |
| MiniApp 7              |
| MiniApp 6 - TCL CHANN  |
| MiniApp 5 - DISNEY     |
| MiniApp 4 - GLOBO PLA  |
| MiniApp 3 - PRIME VIDE |
| MiniApp 2 - YOUTUBE    |
| MiniApp 1 - NETFLIX    |
| MiniApp 0 - GOOGLE - S |
| CABLE                  |
| HDMI 2                 |
| HDMI 1                 |
| TV ANT                 |

Enable the quick start from the TV menu if and possible There is no numercic IR codes. If you have a remote control with this codes and wnat to share, please, sed to us

**Driver Properties:** 

#### **Debug Mode**

On | Off Usado para rastreio de atividade, normalmente pelo desenvolvedor

#### Power On Delay-Milliseconds

Time in milliseconds that it takes the TV to turn on. Default 4000 (4 seconds). Some settings in the TV menu can make the power on faster or slower

#### **Command Delay-Milliseconds**

Interval in ms between commands

#### Press-Release Command Delay-Milliseconds

Interval in ms between repetitive commands when holding the button (volume, navigation arrows and channels). This interval may work better or worse depending on the IR emitter hardware. If the commands continue to come out after releasing the key, increase this value

#### **Alternative Power ON-OFF**

If the TV is not turning off, choose "Yes" in this optionI send the INFO (Home) command to turn on and off, driver send the INFO (which turns on

the TV) and after x seconds sends the power toggle.

### Alternative Power ON-OFF (seconds to OFF)

Time at which the power toogle will be sent after the INFO does not shut down

# Connections, MiniApp Drivers and Smart TV

This driver can use some mini drivers, sending the user to the correct application via IR codeTo do so, connect the Control4 (universal) mini drivers to the corresponding connections (outlined in **red** in the image below:

| MiniApp 0 - GOOGLE - SMART TV | Video | RF_MINI_APP | Input | Google Smart TV->Google TV   |
|-------------------------------|-------|-------------|-------|------------------------------|
| MiniApp 1 - NETFLIX           | Video | RF_MINI_APP | Input | Netflix->Netflix             |
| MiniApp 2 - YOUTUBE           | Video | RF_MINI_APP | Input | YouTube->YouTube             |
| MiniApp 3 - PRIME VIDEO       | Video | RF_MINI_APP | Input | Prime Video->Amazon Prime Vi |
| MiniApp 4 - GLOBO PLAY        | Video | RF_MINI_APP | Input | Globoplay->Globoplay         |
| MiniApp 5 - DISNEY            | Video | RF_MINI_APP | Input | Disney Plus->Disney Plus     |
| MiniApp 6 - TCL CHANNEL       | Video | RF_MINI_APP | Input | TCL Channel->TCL Channel     |
|                               |       |             |       |                              |

The mini drivers with **a blue** outline are present in the .zip file (TCL Channel and Google TV)

Note that the main menu of the Smart TV is accessible by the Google TV Mini Driver or via the **INFO command** 

### Change Log

Versão 1055

31/may/2025

Internacional release