



Driver for Integration NovaStar LED Panel Controllers

Objective:

Integration to the Control4 solution

Requirements:

Control4 **system** running version 2.10 or higher

Propriedades do driver:

Debug Mode

On | Off

Used for activity tracking, typically by the developer

Power On Delay-Milliseconds

Time in milliseconds that it takes the dashboard to turn on. Default 4000 (4 seconds)

Command Delay-Milliseconds

Interval in ms between commands

IP

Enter NovaStar IP. Reserve this IP on DHCP router table or leave fixed on Novastar device

TCP Port

Communication port, standard 5201

IP Conn Status

IP connection information from the driver to the device

Connection

Connection type. Only IP available

Send HEXA

Field for sending codes for tests

Actions

Sending Codes

Programming

Sending Codes

Change Log

Version 1060 06/21/2024 Initial Version