



DOMOSAPIENS AMPLIFIER TRIGGERS DRIVER

This driver enables you to trigger an amplifier when its target rooms become active. While this may be done via programming, using this driver greatly simplifies the process while offering additional functionalities.

INSTRUCTIONS

- Use the free trial period or activate the driver at any time by assigning to this project the license you purchased from the DriverCentral website (requires the DriverCentral cloud driver). You may use multiple copies of this driver in your project.
- Physically connect the Control4 RELAY port to the amplifier's trigger input. You may need to 'borrow' 12V from the Control4 controller or IO Extender and feed it via the relay's NO connection to the amplifier.
- Select the number of triggers (rooms) required for the targeted amplifier. If a given amplifier has several trigger inputs, use as many instances of this driver as required, understanding that each trigger will require one physical Control4 RELAY port.
- Select each individual room and specify if the amplifier will be triggered whenever the room is 'On' or whenever its 'Audio Only' is on (no Video).
- Connect the driver's RELAY binding to the appropriate Control4 Relay Port.

SUPPORT

For support on this driver please go to <https://help.drivercentral.io/>. Give a detailed description of the problem and also include the version number of the driver and the version of Control4 OS that you are using.

AUTO UPDATE

This driver is updated with fixes and new features from time to time. To ensure your project uses the latest version, set the Automatic Updates property of the driver to On.

CHANGELOG

10.0.1 February 7, 2020	Initial Release
10.1.0 September 5, 2020	Licensing update