



**Hibersense**

**HIBERSENSE**  
**QUICK START GUIDE**  
MODULE DEVELOPED BY INTEGRITY SOFTWARES

### Quick Start:

The Hibernsense comfort control two-way module is installed and configured like most other two-way modules.

1. Import the TCM file in Accelerator and restart.
2. Add the module to the project in Step 4:
  - Database: My
  - Module Type: IP Database
  - Category: AUX
  - Brand: INTEGRITY SOFTWARES
  - Model: HIBERSENSE
3. Enter a “dummy” IP address for the module in Step 6.
4. Accelerate in Step 10.
5. Enter the provided authentication information in Step 11.
6. Accelerate in Step 12.
7. Add available two-way commands as needed in your macros.
8. Implement device events as needed in your automation macros.
9. Download to the base station.

This module is designed to work in tandem with the Hibernsense mobile app, Use the mobile app to perform the initial configuration of the Hibernsense hub(s), thermostat, sensors, vents, and scenes.

From the TC module’s UI you’ll be able to see the current system status and activate previously-configured scenes.

