


White Paper: UniFi ViewPort

8.6.2023


Configuring UniFi ViewPort with additional 'views'

Create View on UniFi Protect

- Open UniFi Protect App and Select Live View
- Select the LiveView menu (center-bottom of window) and Select **Add Live View**
- Create your View
 - Setup Cameras, GRID Placement
 - Set Name
- Select Apply Changes
- Go back and Re-open the View you just created (edit / Pencil icon)
- Select Share
 - Enable **Share view with others**
 - Enable **Share on Viewport**
 - Select the Viewport that you want to this *View* to be added to



- In Control4
 - Select the Protect Gateway Driver
 - Driver Action: *Refresh Gateway Connection*



The Driver now will have access to the **View** that was created.

[Developer Information](#)

brought to you by: Cindev



<https://www.cindev.com>

<https://www.drivercentral.io/cindev/>

We are always looking to improve our drivers. Please send your suggestions to:
info@cindev.com